


HE SERIES HOLDERS

WATER COOLED EJECTOR TYPE

Note:
Order Separately
No. 1 and No. 2 Morse
Taper Adapters
Page 27



A DIA.	B LENGTH	C TAPER OR THREAD	HOLDER ASSY. No.	WATER CONNEC- TION ASSY. No. INCLUDES PARTS ① ② ③ ④ ⑥ ⑦	SLIDING TUBE ④	SLIDING TUBE ⑤	KO TUBE ⑧	HEAD SEAL ⑫	BARREL WITH SEALS ⑨ ⑩ ⑫
1	8	1	HE-408-1	WC-E8	H-4-8	H-5	H8-8-1	H-12-4	H1-408
		2	HE-408-2				H8-8-2		H2-408
		7/8 — 14	HE-408-T			H-5	H8-8-T		HT-408
	12	1	HE-412-1	WC-E12	H-4-12	H-5	H8-12-1	H-12-4	H1-412
		2	HE-412-2				H8-12-2		H2-412
		7/8 — 14	HE-412-T			H-5	H8-12-T		HT-412
1 1/4	8	1	HE-508-1	WC-E8	H-4-8	H-5	H8-8-1	H-12-5	H1-508
		2	HE-508-2				H8-8-2		H2-508
		3	HE-508-3				H8-8-3		H3-508
		1—14	HE-508-T			H-5	H8-8-T		HT-508
	12	1	HE-512-1	WC-E12	H-4-12	H-5	H8-12-1	H-12-5	H1-512
		2	HE-512-2				H8-12-2		H2-512
		3	HE-512-3				H8-12-3		H3-512
		1—14	HE-512-T			H-5	H8-12-T		HT-512
1 1/2	8	1	HE-608-1	WC-E8	H-4-8	H-5	H8-8-1	H-12-5	H1-608
		2	HE-608-2				H8-8-2		H2-608
		3	HE-608-3				H8-8-3		H3-608
		1—14	HE-608-T			H-5	H8-8-T		HT-608
	12	1	HE-612-1	WC-E12	H-4-12	H-5	H8-12-1	H-12-5	H1-612
		2	HE-612-2				H8-12-2		H2-612
		3	HE-612-3				H8-12-3		H3-612
		1—14	HE-612-T			H-5	H8-12-T		HT-612